




Brain-Computer Interface for Home Automation

SP2015-02



Overview

1. Introduction
 2. Background
 3. Analysis & Design
 4. Implementation
 5. Demonstration
 6. Testing and Evaluation
 7. Conclusion
-



Introduction



Motivation



Home Automation

“Most home automation systems require physical interactions, which make them unable to support people with motion impairments.”

Paralysis



<http://www.spinal-research.org/wp-content/uploads/2011/09/Image-0444.jpg>

Amyotrophic Lateral Sclerosis (ALS)




http://vignette2.wikia.nocookie.net/epicrapbattlesofhistory/images/1/1a/Stephen_Hawking_Based_On.jpg/revision/latest?cb=20150822054937





MindMagic



Background

Relevant Technologies

Home Automation



<https://www.pm360online.com/the-smart-home/>



NeuroSky®
Body and Mind. Quantified.

Brain-Computer Interface

- EEG (Electroencephalogram) Wearable Device
- Affordable (99.99 USD)
- Easy to Use (Dry Cells, 2 Sensors)
- Bluetooth Connection
- Attention, Meditation, and Blink Detection

Embedded Systems

Arduino Uno

- Microcontroller
- Easy to Use
- Open Source
- Inexpensive



Universal Windows Platform




One Windows Platform

<https://www.blognone.com/node/66491>

Existing Systems

Samsung SmartThings



<http://thetechportal.in/tag/samsung-smart-things/>


A Brain Computer Interface for Smart Home Control

by Wei Tuck Lee, Humaira Nisar, Aamir S. Malik, and Kim Ho Yeap


- Home automation system controlled with brain-computer interface
- Users interacting with GUI (Virtual Home Environment)
- Gyroscope sensor used for controlling a mouse
- Raising eyebrows, blinking, or both for doing a mouse-click




Emotiv EPOC



Analysis & Design




System Architecture




System Design

Structure Chart




Use Case Diagram



I/O Design


UI Design




Panel UI Design

Transition - Panel


Main page



Panel page




TV control options page




AC control options page

Transition - Setting


Main Page



Settings Page



Edit Page





Implementation



Hardware & System Environment


Hardware & Software

Hardware


1. MindWave Mobile Headset
2. Arduino Board
3. USB cable (for uploading arduino program)
4. HC-05 Bluetooth Module
5. IR LED
6. Speaker
7. Relay board
8. Connecting wires
9. Bread board
10. Resistor (100E)
11. Device running on Universal Windows Platform

Software


1. Arduino 1.6.5
2. Visual Studios 2015




Implementation Guide



Pages » MainPage





Pages » MainPage » Panel



Two event handlers:
HandleUpdate()
HandleBlink()

Pages » MainPage » Panel » TVoptions & AOptions



Pages » MainPage » Settings



Three functions:

- Add
- Edit
- Delete

Pages » MainPage » Settings » PortSettings




MindMagicApp

Port 1



Cancel Save

Name: Room Light

Type:

-  Light
-  Fan
-  Other


Pages » MainPage » Training



Pages » MainPage » Training



Average brainwave value
in **normal state**

Average brainwave value
when blinks



Eye-blink
Threshold

Pages >> MainPage >> Help > TryBlink



Classes

1. AppStyle

Contain read-only variables used in the user interface for customizing the look and style.

Classes


2. ArduinoConnection

Handle the communication between the application and the Arduino board.

Classes

3. Data

Handle everything involved with application data.



Classes

4. LogicSettings

- Work with Settings page and PortSettings page.
- Contain constant variables and helper methods.

Classes

5. MindWave

- Establish the connection with the headset.
- Analyze the received packets from the headset.
- Detect eye-blinks.



Demonstration



Demonstration

1. System Configuration
 2. Help
 3. Turning ON/OFF Appliances
 4. Turning ON/OFF Alarm
 5. Training
 6. Controlling Appliances with IR
-





Testing & Evaluation



Testing & Evaluation

1. Unit test
2. Accuracy test
3. Usability test
4. User feedback

Unit Test

Test Description

Objective


A test on each part of the system to see its functionality


Testing Device

1. DELL INSPIRON N5110
Windows 10, CPU 2.3 GHz, RAM 8 GB, Bluetooth
2. MindWave Mobile

Electronic Appliances Used

1. Light Bulb
2. Electric Fan
3. Television
4. Air Conditioner






IR Devices

ON/OFF Devices
(Plug)

Result : Test MindWave Mobile connection

Testing Condition	Details	Results
Pair MindWave mobile with the device Tester wears MindWave Mobile	Test the connection establishment Test the connection status of MindWave Mobile headset: it should show at least yellow or green.	The system can detect signals from MindWave Mobile. The connection status is shown properly.




Result : Test Arduino Connection and Communication

Testing Condition	Details	Results
The device that run the application connects with Arduino's Bluetooth module.	Test if the connection can be established properly.	The Bluetooth module works properly. The connection can be established.


Result : Test Arduino Connection and Communication

Testing Condition	Details	Results
The application sends a command message to Arduino via Bluetooth.	Check if the application can issue a command message in the form of a Bluetooth package and if Arduino can receive the command message from the application correctly.	Arduino receives the command message correctly.



Result : Test controls on ON/OFF devices

Testing Condition	Details	Results
Use the application to turn on/off electronic appliances.	Test the ability to turn on/off the appliances according to the command.	The system can turn on/off electronic appliances.



IR Devices


ON/OFF Devices
(Plug)

Result : Test controls on IR devices

Testing Condition	Details	Results
Starts controlling the level of electronic appliances	Test if the application issue the command correctly	The application issues the command to Arduino properly.

Result : Test controls on IR devices

Testing Condition	Details	Results
Arduino emit IR signal to control IR device	<p>Check if the program emit the correct IR signal code according to the command from the application</p> <p>Check IR transmitter functionality</p>	The system can control IR device properly.



Result : Test Settings function & database connection

Testing Condition	Details	Results
Add an electronic appliance to the panel.	Have a new icon of the new appliance.	The system shows the new icon of a new electronic appliance and save the data onto databases.
Remove an electronic appliance out of the panel.	The icon of the removed appliance disappears.	The system removes the icon of removed appliance and its data from database.

Result : Test Settings function & database connection

Testing Condition	Details	Results
Configure the existing electronic appliance.	Edit name and type of electronic appliance and click save.	The system shows the configure page of the electronic appliances and save the new data to the database.

Accuracy Test

Test Description


Objective

To evaluate the accuracy of the system

Testing Device

1. DELL INSPIRON N5110
Windows 10, CPU 2.3 GHz, RAM 8 GB, Bluetooth
2. MindWave Mobile

Test Procedure




Result



1

MindWave Mobile sends data package in varied amount of time.

The selection box already moved from the desired appliance.



IR Devices

2

MindWave Mobile cannot detect user's eye blinks, or brainwave values do not reach the threshold.

ON/OFF Devices
(Plug)

Result

2s per box



8%
Miss


Result

3s per box



Result

- Selection box speed added to Settings



Usability Test

Test Description

Objective

- To observe how well the users perform specific tasks with the current design of the application
- To observe the problems that occurred when the users use the system

Testing Device

1. Lenovo Y50-70
Windows 10, CPU 2.5 GHz, RAM 8GB, Bluetooth
2. MindWave Mobile

Test Procedure

Scenario ID	Details
Scenarios #1	You want to set the control panel so that you can control a lamp, TV, phone, and alarm. Set port 1 name 'Lamp' type 'light'
Scenarios #2	You want to turn on the lamp but you can't use your hand.
Scenarios #3	You want to turn the tv on and then change the channel up but you can't use your hand.
Scenarios #4	You are an ALS patient. You can't move your body, you can only blink your eyes. You want to call your assistant to help you using the system's alarm.


Result

- Some UI confusion observed
- Some testers were founded **having trouble to finish Scenario#2**
- Testers can finish Scenario#3 and Scenario#4 easily after finishing Scenario#2





Result

- Minor changes in the UI design



- Help page and Try Blink page added



User feedback

“ This system is needed,
but more functions should be added. ”

A Physician at Karnjana Medical Center




Conclusion




Mind Magic



BCI
Headset



MindMagic
Application



Embedded
System

Benefits to...

Motion-Impaired Users

- Being able to control electronic appliances inside their houses without moving their limbs
- Being more independent

Assistants

- Having less workloads

Problems and Limitations

- Bluetooth Signal Limitation
- Blink Detection Accuracy
- Battery Life of EEG Headset
- Access to target users

Future Work

- Develop a Thai version of the application.
- Improve the accuracy of the system.
- Replace Bluetooth with WiFi
for the connection between the *engine* and the *Arduino board*.
- Support more electronic appliances.

Acknowledgement

- BaanPhrapradaeng
- National Software Contest 2016
- Imagine Cup Thailand 2016
- Test Participants

Q&A

Thank you.